



## RIGHT-ANGLE DRIVE

---

### ASSEMBLY DESCRIPTION

---

A Right-Angle Drive allows the operator to separate the Veeder Root Counter from the Measuring Head Assembly. The Right-Angle Drive can also be used to change the ratio between the Measuring Head Assembly and the Veeder Root Counter.

