




G STOP RUNNING TOOL

ASSEMBLY DESCRIPTION

The G Stop Running Tool is used to set G Stop Anchors.





G STOP RUNNING TOOL

SPECIFICATIONS			
	2.000	2.500	3.000
Fishneck	1.375	1.375	1.750
Connections	15/16"-10	15/16"-10	1-1/16"-10
Shear Pin	1/8" X 1-13/16"	1/8" X 2-3/16"	3/16" X 2-11/16"
Set Screw	1/4"-20 X 5/16"	3/8"-16 X 1/2"	3/8"-16 X 1/2"

All Specification Tables contain approximated dimensions and should be used for reference only.