



LINK JAR

ASSEMBLY DESCRIPTION

The Link Jar provides extra weight in order to increase the impact needed to operate certain wireline tools. The intensity is dependent upon the weight of the Stem above it, the stroke of the jar, the density and viscosity of the well fluid, and the well pressure.





LINK JAR

SPECIFICATIONS				
	.750	1.000	1.250	1.500
Fishneck	0.750	1.000	1.188	1.375
Connections	1/2"-13	5/8"-11	15/16"-10	15/16"-10

SPECIFICATIONS				
	1.750	1.875	2.125	2.500
Fishneck	1.750	1.750	1.750	2.313
Connections	1-1/16"-10	1-1/16"-10	1-1/16"-10	1-9/16"-10

All Specification Tables contain approximated dimensions and should be used for reference only.