




PRS PULLING TOOL

ASSEMBLY DESCRIPTION

The PRS Pulling Tool is a shear releasing tool used in pulling subsurface devices which have internal fishnecks. The PRS Pulling Tool can be configured to shear up or down depending upon the pulling operations.





PRS PULLING TOOL

SPECIFICATIONS			
	2.000	2.500	4.000
Fishneck	1.375	1.375	2.313
Maximum O.D.	1.820	1.820	3.500
Connections	15/16"-10	15/16"-10	1-1/16"-10

All Specification Tables contain approximated dimensions and should be used for reference only.