



REPINNING TOOL

ASSEMBLY DESCRIPTION

The Repinning Tool is used to put Shear Pins into B & T Running Tools and Pulling Tools.

