



TREE CONNECTION

ASSEMBLY DESCRIPTION

Tree Connections are used to connect the bottom of the wireline valve to the connection at the top of the tree.

B & T manufactures a wide range of Tree Connection sizes upon customer specification.

B & T will also build special crossovers for pipe threads, including but not limited to EUE connections for Landing Nipples.

