



VEEDER ROOT COUNTER

ASSEMBLY DESCRIPTION

The Veeder Root Counter is attached to the Measuring Head Assembly or it can be adapted through a remote cable. It calculates the depth of the tool string during wireline operations, as the wire is lowered downhole.

The Veeder Root Counter is available with readings in meters or feet to accommodate customer specifications.

B & T also repairs used Veeder Root Counters.

