



## STEM

---

### ASSEMBLY DESCRIPTION

---

Stem is used to add weight to the tool string to counteract upward well bore pressure. This allows easy descent of the tool string. It is also used to increase the jarring effect of Link Jars and Tubular Jars. Tungsten Stem is available upon customer request, and will add significantly more weight per square inch.





# STEM

SPECIFICATIONS			
0.500			
Length	2'	3'	5'
Fishneck	0.500	0.500	0.500
Connections	3/8"-16	3/8"-16	3/8"-16
Weight	0.670	2.000	3.350

SPECIFICATIONS			
0.750			
Length	2'	3'	5'
Fishneck	0.625	0.625	0.625
Connections	1/2"-13	1/2"-13	1/2"-13
Weight	3.000	2.000	3.350

SPECIFICATIONS			
1.000			
Length	2'	3'	5'
Fishneck	0.875	0.875	0.875
Connections	5/8"-11	5/8"-11	5/8"-11
Weight	5.300	7.800	12.000

SPECIFICATIONS			
1.250			
Length	2'	3'	5'
Fishneck	1.188	1.188	1.188
Connections	15/16"-10	15/16"-10	15/16"-10
Weight	7.800	12.000	20.400

All Specification Tables contain approximated dimensions and should be used for reference only.



# STEM

SPECIFICATIONS			
1.500			
Length	2'	3'	5'
Fishneck	1.375	1.375	1.375
Connections	15/16"-10	15/16"-10	15/16"-10
Weight	11.000	17.000	29.200

SPECIFICATIONS			
1.750			
Length	2'	3'	5'
Fishneck	1.750	1.750	1.750
Connections	1-1/16"-10	1-1/16"-10	1-1/16"-10
Weight	17.500	26.800	46.000

SPECIFICATIONS			
2.125			
Length	2'	3'	5'
Fishneck	1.750	1.750	1.750
Connections	1-1/16"-10	1-1/16"-10	1-1/16"-10
Weight	24.100	36.200	53.400

SPECIFICATIONS			
2.500			
Length	2'	3'	5'
Fishneck	2.313	2.313	2.313
Connections	1-9/16"-10	1-9/16"-10	1-9/16"-10
Weight	33.400	50.100	83.500

All Specification Tables contain approximated dimensions and should be used for reference only.